



Art. 161.0368-R004P

Art.-Nr.	Description	Beschreibung	Menge Qty.
161.0365-R010P-18	Spring	Feder	1
161.0365-R010P-21	O-Ring	O-Ring	1
161.0365-R010P-22	Screw	Schraube	1
161.0365-R010P-26	Release valve	Ablassventil	1
161.0365-R010P-34	Pump core base	Pumpkolbenführung	1
161.0365-R010P-39	Pump core base	Pumpkolben	1
161.0365-R010P-40	Spring retainer	Federhalterung	1
161.0365-R010P-41	Retainer ring	Sprengring	1
161.0365-R010P-46	Steel ball	Stahlkugel	1
161.0365-R010P-47	Valve	Ventil	1
161.0365-R010P-48	Filter	Filter	1
161.0365-R010P-50	O-Ring	O-Ring	2
161.0368-R004P-01	Retainer ring	Sprengring	1
161.0368-R004P-02	Distance ring	Abstandsring	1
161.0368-R004P-03	Piston rod	Kolbenstange	1
161.0368-R004P-04	Washer	Unterlegscheibe	1
161.0368-R004P-05	O-Ring	O-Ring	1
161.0368-R004P-06	Piston mounting	Kolbenführung	1
161.0368-R004P-07	Nylon washer	Nylondichtring	1
161.0368-R004P-08	Filter	Filter	2
161.0368-R004P-09	Reflux valve	Rücklaufventil	3
161.0368-R004P-10	Steel ball	Stahlkugel	4
161.0368-R004P-11	Screw	Schraube	1
161.0368-R004P-12	Hydraulic housing	Hydraulikgehäuse	1
161.0368-R004P-13	Oil hose	Ölschlauch	1
161.0368-R004P-14	Oil tank	Öltank	1

Art.-Nr.	Description	Beschreibung	Menge Qty.
161.0368-R004P-15	Screw	Schraube	1
161.0368-R004P-16	Oil plunger	Ölstöpsel	1
161.0368-R004P-17	Steel ball	Stahlkugel	1
161.0368-R004P-18	Screw	Schraube	1
161.0368-R004P-19	Copper washer	Kupferdichtring	1
161.0368-R004P-20	Pump core base	Pumpkolbenführung	1
161.0368-R004P-21	Spring	Feder	1
161.0368-R004P-22	O-Ring	O-Ring	2
161.0368-R004P-23	Washer	Unterlegscheibe	2
161.0368-R004P-24	Pump core base	Pumpkolben	1
161.0368-R004P-25	Protection sleeve	Schutzhülse	1
161.0368-R004P-26	O-Ring	O-Ring	1
161.0368-R004P-27	Distance ring	Abstandsplatte	1
161.0368-R004P-28	Bolt	Bolzen	1
161.0368-R004P-29	Copper washer	Kupferdichtring	1
161.0368-R004P-30	O-Ring	O-Ring	2
161.0368-R004P-31	Nylon washer	Nylondichtring	2
161.0368-R004P-32	Spring	Feder	1
161.0368-R004P-33	Protection sleeve	Schutzhülse	1
161.0368-R004P-34	Steel ball	Stahlkugel	1
161.0368-R004P-35	Steel ball base	Stahlkugelhalterung	1
161.0368-R004P-36	Spring	Feder	1
161.0368-R004P-37	Screw	Schraube	2
161.0368-R004P-38	Nut	Mutter	1
161.0368-R004P-39	Retainer ring	Sprengring	1
161.0368-R004P-40	Washer	Unterlegscheibe	1